

## 70 Warns you inside the home

# Alarm Siren Indoor

The indoor siren is mainly for your safety i. e. in case of a fire alarm. It is not there to warn off intruders who may when fleeing cause in their panic even more damage.

Every available detector (i. e. Smoke Detector, Motion Detector) can not only route the alarm to any telephone but also to the alarm siren for added safety.



### Technical Data

Dimension:  
**126 x 58 x 68 mm**  
Weight:  
**180 g**  
Temperature Range:  
**-10 to +55° C**  
Frequency:  
**868,3 MHz**  
Battery operated:  
**AA 3 x 1,5 V**  
Siting:  
**Indoors (IP44)**  
Volume:  
**100 db (3 mtr)**



Standard Radio Module  
Required

Warns neighbours and authorities  
and fights off „none desirables“

# Alarm Siren Outdoor

The outdoor siren is used to scare off burglars which may have opened or broken a window. It also will make the neighbourhood aware that you are visited by a burglar.

We would also like to suggest to trigger a silent alarm. Please consult your local security service or police.



### Technical Data

Dimension:  
**323 x 240 x 97 mm**  
Weight:  
**2,9 kg**  
Temperature Range:  
**-10 to +55° C**  
Frequency:  
**868,3 MHz**  
Battery operated:  
**LR 20 4 x 1,5 V**  
Siting:  
**Outdoors (IP34)**  
Volume:  
**100 dB (3 mtr)**



### Expert Advice!

The alarm and notification of the different detectors can be forwarded to any telephone including your mobile phone.